

# SMART80 & VIPER 3 IGNITION JUMPER

If your dash is constantly on even with the keys turned off, please go under the helm and disconnect this jumper located on the relay next to the Power10 Module.

If you are needing to power the helm/dash without a motor, please re-connect the jumper.

Once a motor is rigged up, the jumper needs to be disconnected.

