



POWER BIMINI TOP
INSTRUCTIONS FOR PROPER OPERATION

NOTICE

- **ALWAYS** have the protective boot installed, except for the FULL OPEN position.
- **ALWAYS** remain on the UP/DOWN button until the unit turns itself off.
- **ALWAYS** store the PWR-ARM in the Full Down position with the boot on when not in use.

WARNING

- **NEVER** attempt to operate the top while the boat is in motion.
- **NEVER** exceed 25 MPH without the boot properly installed.
- **NEVER** open the top in excessively high winds.
- **NEVER** trailer the boat without the boot on in the full down position



FULL OPEN POSITION- MAXIMUM SHADE

Proper Operation

1. Remove protective boot
2. Depress and hold UP button on helm until motors turn off on their own – do not release button until motors turn off
3. Speed Limit in this position 25 MPH
4. Do not open in excessively high winds



VARI-PITCH POSITION – SHADE DURING LOW SUN

Proper Operation

1. Remove protective boot
2. Depress and hold UP/DOWN button on helm until desired position is reach and then release button.
3. Speed Limit in this position 5 MPH
4. Do not open in excessively high winds



RADAR POSITION – REAR ENTRY/EXIT

Proper Operation

1. Install protective boot
2. Depress and hold UP button on helm until motors turn off on their own – do not release button until motors turn off
3. Speed Limit in this position 50 MPH



FULL DOWN POSITION – LIFTS/BRIDGES/STORAGE

Proper Operation

1. Install protective boot for storage and road travel.
2. Depress and hold DOWN button on helm until motors turn off on their own
3. Speed Limit with boot installed 65 MPH
4. Speed Limit without boot installed 5 MPH